



# BT-Ex1-000F-M for Ex-Lin 3L-5L 1

holder across, 0 degrees / for pole diameters of 42 – 60mm





explosion  
proof  
experts

**ATEX**  
WORKSHOP

ATEX Workshop B.V.  
Hofkamp 30  
6161 DC Geleen  
+31 46 303 09 08  
[www.atexworkshop.com](http://www.atexworkshop.com)

# BT-Ex1-090F-M for Ex-Lin 3L-5L 1

holder across, 90 degrees / for pole diameters of 42 – 60mm




explosion  
proof  
experts

**ATEX**  
WORKSHOP

ATEX Workshop B.V.  
Hofkamp 30  
6161 DC Geleen  
+31 46 303 09 08  
[www.atexworkshop.com](http://www.atexworkshop.com)

# BT-Ex1-105F-M for Ex-Lin 3L-5L 1

holder across, 105 degrees / for pole diameters of 42 – 60mm




explosion  
proof  
experts

**ATEX**  
WORKSHOP

ATEX Workshop B.V.  
Hofkamp 30  
6161 DC Geleen  
+31 46 303 09 08  
[www.atexworkshop.com](http://www.atexworkshop.com)

# BT-Ex1-120F-M for Ex-Lin 3L-5L 1

holder across, 120 degrees / for pole diameters of 42 – 60mm






explosion  
proof  
experts

**ATEX**  
WORKSHOP

ATEX Workshop B.V.  
Hofkamp 30  
6161 DC Geleen  
+31 46 303 09 08  
[www.atexworkshop.com](http://www.atexworkshop.com)

# BT-Ex2-090F-M for Ex-Lin 5L-10L 2

holder across, 90 degrees / for pole diameters of 42 – 60mm






explosion  
proof  
experts

**ATEX**  
WORKSHOP

ATEX Workshop B.V.  
Hofkamp 30  
6161 DC Geleen  
+31 46 303 09 08  
[www.atexworkshop.com](http://www.atexworkshop.com)

# BT-Ex2-105F-M for Ex-Lin 5L-10L 2

holder across, 105 degrees / for pole diameters of 42 – 60mm







explosion  
proof  
experts

**ATEX**  
WORKSHOP

ATEX Workshop B.V.  
Hofkamp 30  
6161 DC Geleen  
+31 46 303 09 08  
[www.atexworkshop.com](http://www.atexworkshop.com)

# BT-Ex1-090F-W for Ex-Lin 3L-5L 1

holder across, 90 degrees / for wall mounting







explosion  
proof  
experts

**ATEX**  
WORKSHOP

ATEX Workshop B.V.  
Hofkamp 30  
6161 DC Geleen  
+31 46 303 09 08  
[www.atexworkshop.com](http://www.atexworkshop.com)

# BT-Ex1-105F-W for Ex-Lin 3L-5L 1

holder across, 105 degrees / for wall mounting



explosion  
proof  
experts


**ATEX**  
WORKSHOP

ATEX Workshop B.V.  
Hofkamp 30  
6161 DC Geleen  
+31 46 303 09 08  
[www.atexworkshop.com](http://www.atexworkshop.com)



# BT-Ex1-120F-W for Ex-Lin 3L-5L 1

holder across, 120 degrees / for wall mounting







explosion  
proof  
experts

**ATEX**  
WORKSHOP

ATEX Workshop B.V.  
Hofkamp 30  
6161 DC Geleen  
+31 46 303 09 08  
[www.atexworkshop.com](http://www.atexworkshop.com)

# BT-Ex2-090F-W for Ex-Lin 5L-10L 2

holder across, 90 degrees / for wall mounting







explosion  
proof  
experts

**ATEX**  
WORKSHOP

ATEX Workshop B.V.  
Hofkamp 30  
6161 DC Geleen  
+31 46 303 09 08  
[www.atexworkshop.com](http://www.atexworkshop.com)

# BT-Ex2-105F-W for Ex-Lin 5L-10L 2

holder across, 105 degrees / for wall mounting



explosion  
proof  
experts

**ATEX**  
WORKSHOP

ATEX Workshop B.V.  
Hofkamp 30  
6161 DC Geleen  
+31 46 303 09 08  
[www.atexworkshop.com](http://www.atexworkshop.com)